



Fernsteuerfrequenzen für den Modellbau

RC-Netzwerk Modellsport e.V.
Redaktion RC-Netzwerk Magazin

Zypern/Cyprus/Cyprie



Frequenz MHz (10kHz)	Kanal-Nr.	Verwendung
40,665		BA
40,675		
40,685		
40,695		
40,705		
40,715		
40,725		
40,735		
40,745		
40,755		
40,765		
40,775		
40,785		
40,795		
40,805		
40,815		
40,825		
40,835		
40,845		
40,855		
40,865		
40,875		
40,885		
40,895		
40,905		
40,915		
40,925		
40,935		
40,945		
40,955		
40,965		

Frequenz MHz (10kHz)	Kanal-Nr.	Verwendung
35,010	61	F
35,020	62	
35,030	63	
35,040	64	
35,050	65	
35,060	66	
35,070	67	
35,080	68	
35,090	69	
35,100	70	
35,110	71	
35,120	72	
35,130	73	
35,140	74	
35,150	75	
35,160	76	
35,170	77	
35,180	78	
35,190	79	
35,200	80	

Frequenz MHz (10kHz)	Kanal-Nr.	Verwendung
27,000		S

F	Nur Flugmodelle / airplanes only / seulement pour modèles volants / solamente para aviones
BA	Nur Schiffs- und Automodelle / Modelboats and cars only / seulement pour bateaux et autos / solo per navi e automodelli / solamente para barcas y coches
S	Spielzeug/Toys/Jouet/Juguete